



Better Chemistry. **Better Business.**

**Black-Magic™ RT-S20/25 Replenisher XC**

Product Code: 2260017  
Revised Date: 01/14/2013

### **Black-Magic™ RT-S20/25 Replenisher XC** Room Temperature Blackening Solution For Iron And Steel

**Black-Magic™ RT-S20/25 Replenisher XC** liquid concentrate is used for replenishment and maintenance of both **Black-Magic™ RT-S20** and **Black-Magic™ RT-S25** baths that have a high metals consumption and low drag-out.

#### **SOLUTION REPLENISHMENT AND MAINTENANCE**

The blackening solution is gradually depleted through use, but may be replenished indefinitely with periodic additions of the **RT-S20/25 Replenisher XC** and/or the starting make up concentrate.

The frequency of additions will depend upon the volume of the work processed. For optimum results, the solution should be maintained at 85% of its original strength or better with frequent small additions.

The life and the coverage of the solution will be increased by continuous circulation and filtration.

#### **BURET CONTROL PROCEDURE**

##### EQUIPMENT REQUIRED

250 ml Erlenmeyer Flask  
25 ml Graduate Cylinder

50 ml Burette  
Burette Clamp  
Ring Stand

##### CHEMICALS REQUIRED

6N (1:1) Hydrochloric Acid  
Potassium Iodide - 15% Solution  
(by weight)  
0.1N Sodium Thiosulfate  
0.2% Soluble Starch Solution

#### **CONTROL PROCEDURE**

A sample of a freshly prepared production bath should always be taken as a control solution prior to running any parts through the bath. If a sample was not taken, a laboratory prepared sample at the same concentration may be used as the control solution. Titration of this "new" solution will provide the figure for  $V_1$ .



## Product Bulletin

Better Chemistry. **Better Business.**

**Black-Magic™ RT-S20/25 Replenisher XC**

**Product Code: 2260017**  
**Revised Date: 01/14/2013**

1. Transfer a 25 ml sample of the production bath into the 250 ml Erlenmeyer flask.
2. Dilute with water to the 100 ml mark.
3. Add 10 ml 6N (1:1) Hydrochloric Acid to the flask.
4. Add 20 ml of the 15% by weight Potassium Iodide solution.
5. Swirl the solution once, stopper and store in the dark for 10 minutes.

**NOTE:** Only glass or aluminum foil covered stoppers should be used.

6. Add 10 ml of starch solution. The solution will become a dark blue-green to almost black color. Titrate with the 0.1N Sodium Thiosulfate solution until the dark black color changes to a light brown.

### **PLEASE NOTE**

Upon standing, the light brown color will turn dark again, but additional Sodium Thiosulfate solution should NOT be added. The first end point is correct.

7. Calculate the amount of concentrate to be added as follows:

$$C_2 = \frac{V_1 - V_2}{V_1} \times \frac{(C_1)}{2}$$

$C_2$  = Concentrate in gallons to be added to bath

$V_1$  = Milliliters of Sodium Thiosulfate used to titrate the new production bath.

$V_2$  = Milliliters of Sodium Thiosulfate used to titrate the used production bath.

$C_1$  = Volume of concentrate in gallons used to make up the original **RT-S20** or **RT-S25** "new" bath.



Better Chemistry. Better Business.

**Black-Magic™ RT-S20/25 Replenisher XC**

**Product Code: 2260017**  
**Revised Date: 01/14/2013**

### **EXAMPLE**

Black-Magic™ RT-S20, "new" solution, 9 to 1 dilution  $V_1 = 27.5$

A 100 gallon bath made up at 10% by volume of concentrate (i.e. 10 gallons of concentrate in 90 gallons of water) is titrated and the additions to the bath calculated as follows:

$$V_1 = 27.5$$

$$V_2 = 25.44$$

$$C_1 = 10 \text{ gallons}$$

$$C_2 = \frac{27.5 - 25.44}{27.5} \times (10)$$

$$C_2 = \frac{2.06}{27.5} (5) \text{ or } \frac{10.3}{27.5}$$

$C_2 = 0.375$  gallons **RT-S20/25 Replenisher XC** to be added to production bath.

### **DROPPING BOTTLE CHEMICAL CONTROL PROCEDURE**

#### EQUIPMENT REQUIRED

125 ml Erlenmeyer Flask

10 ml Graduate Cylinder

125 ml Dropping Bottle

#### CHEMICALS REQUIRED

6N (1:1) Hydrochloric Acid

Potassium Iodide - 15% Solution  
(by weight)

0.5N Sodium Thiosulfate

0.2% Soluble Starch Solution

### **CONTROL PROCEDURE**

A sample of a freshly prepared production bath should always be taken as a control solution prior to running any parts through the bath. If a sample was not taken, a laboratory prepared solution at the same concentration may be used as the control solution. Titration of this "new" solution will provide the figure for  $D_1$ .

1. Transfer a 5 ml sample of the production bath into the 125 ml Erlenmeyer flask.
2. Dilute with water to the 50 ml mark.



Better Chemistry. Better Business.

### Black-Magic™ RT-S20/25 Replenisher XC

Product Code: 2260017  
Revised Date: 01/14/2013

3. Add 2 ml 6N (1:1) Hydrochloric Acid to the flask.
4. Add 4 ml of the 15% by weight Potassium Iodide solution.
5. Add 2 ml of starch solution. The solution will become a dark blue to almost black color.
6. Add the 0.5N Sodium Thiosulfate solution, from the dropping bottle - drop by drop - counting the drops while swirling the flask.
7. The end point is marked by a sudden change in color from dark black to light brown.

**NOTE:** Upon standing, the light brown color will turn dark again, but additional Sodium Thiosulfate solution should not be added. The first end point is correct.

8. Calculate the amount of concentrate to be added as follows:

$$C_2 = \frac{D_1 - D_2}{D_1} \times \frac{(C_1)}{2}$$

$C_2$  = Concentration in gallons to be added to the bath.

$D_1$  = Number of drops of Sodium Thiosulfate used to titrate the new production bath.

$D_2$  = Number of drops of Sodium Thiosulfate used to titrate with used production bath.

$C_1$  = Volume of concentrate in gallons used to make up the original "new bath".

A 100 gallon bath made up at 10% by volume of concentrate (i.e. 10 gallons of concentrate in 90 gallons of water) is titrated and the additions to the bath calculated as follows:

$$D_1 = 27$$

$$D_2 = 24$$

$$C_1 = 10 \text{ gallons}$$

$$C_2 = \frac{27 - 24}{27} \times \frac{10}{2}$$



## Product Bulletin

Better Chemistry. **Better Business.**

**Black-Magic™ RT-S20/25 Replenisher XC**

**Product Code: 2260017**  
**Revised Date: 01/14/2013**

$$C_2 = \frac{3}{27} (5) \text{ or } \frac{15}{27}$$

$C_2 = 0.55$  gal of concentrate to be added to the production bath.

### **NOTE**

The volumes used in the above equation may be metric or English (i.e. quarts, liters, gallons).

### **CAUTION**

The **RT-S20/25 Replenisher XC** solution is mildly acidic. Avoid contact with eyes, skin and clothing. Wear eye shields, protective gloves and apron. The solutions are toxic if taken internally.

### **WARRANTY**

THE QUALITY OF THIS PRODUCT IS GUARANTEED ON SHIPMENT FROM OUR PLANT. IF THE USE RECOMMENDATIONS ARE FOLLOWED, DESIRED RESULTS WILL BE OBTAINED. SINCE THE USE OF OUR PRODUCTS IS BEYOND OUR CONTROL, NO GUARANTEE EXPRESSED OR IMPLIED IS MADE AS TO THE EFFECTS OF SUCH USE, OR THE RESULTS TO BE OBTAINED.